

INSTALLATION INSTRUCTION

Model	Product	Code
HONDA X ADV 750 21+	Front Fender Beak Extension	FB-HXADV21



CONTENTS

1. 1pcs Plastic part
2. 3pcs Support Component (I2-FB-HXADV-SET)
3. 6pcs M6X16 Allen screws with round head
4. 2pcs M5X15 Allen screws with round head
5. 4pcs M6 Security nuts
6. 4pcs 6X18 Washers
7. 2pcs M6 Encased square nuts

MATERIAL DESCRIPTION

The product is made of ABS plastic in glossy black color
The support parts are made of Inox 2mm thick.
The screws, nuts, and washers are galvanized in silver color.



These are the contents you will find inside the product package as well as a card containing the link to download the leaflet with the detailed installation instructions and step-by-step rich photographic material.

Before starting the installation, read the instructions carefully so that you know if you have the right tools and skills, otherwise contact a professional.

The product is for race use only

For any further information please do not hesitate to contact us: Tel.: +30 2108075387 Email: info@c-racer.com



First press the inner pin (left and right) of the clip of the internal plastic cover and then remove it.



Do the same with the two clips in the front part of the plastic cover.



Open the side cover with your hands, find the allen screws on each side and remove them.



Now you can remove the entire front cover, as the photo shows. Keep it in case you need to restore it in the future.



Place the support parts as shown in the photo.
Before tightening them make sure that they are parallel
to the plastic cover.



Place the encased square nuts in the front,
as the photo shows. Put them in the center of the hole
of the plastic cover.



Screw the other part in the position shown in the photo.
Encased square nuts must be held with your hand
to be able to secure the screw (not presented in the
photo for photography reasons).



Place the plastic fender and screw it to the back
part, as the photo shows.



Screw the front part as well, as shown in the photo. Finally put back the two clips (left and right) that hold the cover.



This will be your final result. Happy and safe rides.