

INSTRUCTION

Model	Product	Code
Yamaha XJR 1200/1300 '02-'06	Side Number Plate	SNP-XJR

You are advised to read the instructions carefully, before you proceed to any changes.

Any modifications on your motorcycle should be performed by specialized personnel, however the installation process of this product is quite easy if you follow the instructions below.



CONTENTS

2 X Plastic Plate

6 X screws M6X15 (allen-round head-washer)

4 X slide clips M6



Remove the side covers and the rubbers used for locking the OM panels. Install in rubbers place the M6 slide clips as shown in the image



Do the same at the rear end brackets as shown In the image. (again fitting the slide clips)

_







Place the new covers and tighten with the provided bolts. There is the chance of needing of small adjustment of the sliding clips in order to have the covers perfectly aligned. Finally tighten firmly the bolts



The end result should appear as in the photo Thank you for choosing one of our products.