



**C-RACER**  
www.c-racer.com

# INSTRUCTION

Model	Product	Code
BMW K75/100 82-95	Scarbler/Café Racer Front Fender	FF-BMWK

No modification required on your motorcycle in order to install this product.  
Read the instructions carefully before proceeding with the steps provided below.  
It is required to have the front fork bridge because that is the point where the fender will be attached.  
**It is advisable that these actions are performed by specialized personnel.**

## CONTENTS

- 1 X Plastic Fender
- 4 X screws M6X20 (allen-roundhead-washer)
- 4 X washer 6X18



Remove the old fender.  
Take the new fender and slide it through and under the forks' base – then place back the bridge and use the new screws in their previous position to secure in place.  
Once you have placed all four screws tighten them.

If you do not wish to use the bridge ,  
you may use your own nuts and screws –  
it is not advised as the result will not be very appealing as it will leave a visible gap beneath the bridge.



The end result is as shown in the photos above.  
Thank you for choosing one of our products.

**The product is for race use only**

For any further information please do not hesitate to contact us: Tel.: +30 2108075387 Email: [info@c-racer.com](mailto:info@c-racer.com)

